

Decking oil finish user's guide

ALIS 579

SUITABLE FOR ALL TYPES OF WOOD*

*Please allow cedar to age a minimum of 6 months before applying the oil.

Considering the ecological composition of our products, we recommend cleaning only using GLOUROS 1806. Any other cleaning or surface preparation product could hinder proper oil adhesion.

Step 1 SURFACE PREPARATION

The wood must be completely dry, dust free and non-sealed. We recommend refreshing the oxidized surface by sanding the wood with a 100 grit sanding paper.

Apply at temperature of at least 10°C and make sure the temperature remains over 10°C for at least 8 hours after application.

Step 2 APPLYING THE FIRST COAT

Stir well with a stick to evenly mix the color pigments in the oil. Apply the stain to a small area to confirm your color choice (see note 1). Apply the coat with a brush, spray gun, applicator pad or with a roller just enough to saturate the wood. Let the surface absorb the oil for about 5 minutes then equalize the surface with a brush and make sure the surface is uniform.

Wait about 18 hours before the second coat

Note 1

As our products are colored using natural pigments, there may be minor variations between batches. The wood treatment and age may also influence color absorption, and final results may vary accordingly. We are not responsible for the final color obtained in the event no sampling was done or if multiple oils were blended.

Step 3 APPLYING THE SECOND COAT

Apply the second coat more sparingly and equalize the surface with a brush after 5 to 10 minutes.

On sidings, windows frame or other surfaces, a third coat is recommended; use the same process as step 3.

CLEANING

We recommend washing the terraces every year with GLOUROS 1806

CARE

Wash with GLOUROS 1806 and refresh the surface with a new coat of ALIS 579 as soon as the surface shows signs of wear or become extremely tarnished. (Usually every year on terrace, and 3 to 5 years on siding)

WARNINGS

TO AVOID SPONTANEOUS COMBUSTION RISKS, RAGS, POLISHING DISCS AND OIL IMPREGNATED APPLICATOR PADS MUST BE PLACED IN A METALLIC SEALED CONTAINER OR SUBMERGED IN WATER BEFORE THEIR DISPOSAL.



ECOLOGICAL
WOOD STAINS
AND FINISHES