

Fence oil user's guide DONNOS 223

SUITABLE FOR ALL TYPES OF WOOD

Considering the ecological composition of our products, we recommend cleaning only using GLOUROS 1806. Any other cleaning or surface preparation product could hinder proper oil adhesion.

Step 1 SURFACE PREPARATION

The wood must be completely dry, dust free and non-sealed.

Step 2 COAT APPLICATION

Stir well with a stick to evenly mix the color pigments in the oil.

Apply the stain to a small area to confirm your color choice (see note 1).

Apply 3 fine coats in 24-48 hour intervals. Let the surface absorb the oil for a few minutes then equalize the surface with a brush and make sure the surface is uniform.

Note 1

As our products are colored using natural pigments, there may be minor variations between batches. The wood treatment and age may also influence color absorption, and final results may vary accordingly. We are not responsible for the final color obtained in the event no sampling was done or if multiple oils were blended.

IDEAL APPLICATION TEMPERATURE

15°C to 25°C

CLEANING

We recommend washing every year with GLOUROS 1806

CARE

As soon as the surface shows signs of wear or become extremely tarnished, wash with GLOUROS 1806, and proceed with a light sanding, if needed. Remove the dust and refresh the surface with a two fresh coats of DONNOS 223, at a 24-48 hour interval.

WARNINGS

TO AVOID SPONTANEOUS COMBUSTION RISKS, RAGS, POLISHING DISCS AND OIL IMPREGNATED APPLICATOR PADS MUST BE PLACED IN A METALLIC SEALED CONTAINER OR SUBMERGED IN WATER BEFORE THEIR DISPOSAL.



ECOLOGICAL
WOOD STAINS
AND FINISHES