

## Technical Data Sheet

# KERACOTT First Care No. 380

<b>Application range</b>	In the interior, for the first treatment of KERACOTT – floors or clinker cotto. Also for other hard-fired, low absorbent, unglazed floor tiles.
<b>Technical qualities</b>	Results after polishing in satin glossy, water and grease repellent finish.
<b>Full declaration</b>	Isoaliphates, linseed oil, linseed oil – stand oil – natural resin ester, micronized wax, orange oil, linseed oil – stand oil, beeswax, carnauba wax, pine oil, rosemary oil, alumina, dehydrated amino sugar, bentonite, ethanol, and drying agents free of lead (Ca, Co, Zr).
<b>Color</b>	Product: light – greenish – yellow KERACOTT becomes slightly darker through the treatment.
<b>Application method</b>	Stir or shake thoroughly. Spread evenly with a flat brush or lint-free cloth. Dried coating must be polished (see reverse)
<b>Coverage</b>	1 liter (1.06 quart) is sufficient for approximately 16 m <sup>2</sup> (172 ft <sup>2</sup> ), i.e. 63 ml/m <sup>2</sup> .
<b>Drying time</b>	At 23 °C (73 °F) and 50% relative humidity: 24 - 48 hours. Do NOT enter floor during drying time.
<b>Cleaning</b>	Clean tools immediately after use with SVALOS Thinner No. 222 or LEVO Brush Cleaner No. 997.
<b>Specific gravity</b>	Approximately 0.80 g/ml.
<b>Safety advice</b>	<p>Always be sure to store and then dispose of cleaning cloths, polishing pads, sponges, etc. that are still wet or even slightly moist with KERACOTT First Care No. 380 in an airtight metal container or in water, as there is a danger of spontaneous combustion caused by the plant oil content.</p> <p>The product itself will not combust spontaneously. Contains Limonene and Cobalt (2+) salts. Can cause allergic reactions.</p> <p>S 2 Keep out of the reach of children. S 62 If swallowed, do not induce vomiting; seek medical advice immediately and show this container or label.</p>
<b>Disposal</b>	According to local official regulations.
<b>Container sizes</b>	0.75 l; 2.5 l; 10 l; 30 l.
<b>Storage</b>	Cool and dry. Shelf life: unopened at least 4 years. Close unused product tightly.
	See reverse for more application instructions.

How to use

## **KERACOTT First Care No. 380**

- Preparation** After laying and grouting clean the floor residue-free with GLOUROS Cement Residue Remover No. 1808 and wash afterwards with water. By remaining alkalinity, the joints can appear dappled, these “shadows” can go back after a few months. Let the floor dry (well ventilated) for at least 3 days and if necessary protect against soiling with corrugated cardboard (do NOT use plastic).  
For the first treatment the floor must be absolutely clean and dry.
- Application** Apply once evenly and thinly with a flat brush or lint-free cloth. Test application.  
After 1 -2 days of drying time, polish the surface with a brush, single-disc machine or polishing pad or similar until a satin gloss is achieved.
- Cleaning and Care** With TRENA pH-Neutral Cleaner No. 556 or LATIS Natural Intensive Cleaner No. 551. Be sure to follow the recommended dosage. In case of wear after strong usage, do after-care with KERACOTT First Care.

These directions are the result of long years of research and practical testing. They are backed by our most current expert information. New findings may invalidate this information. The latest version is available on our website at [www.livos.de](http://www.livos.de). This data sheet is meant to serve as information and instruction. No legal liability should be interpreted from it. In case of doubt, please contact the retailer, wholesaler, or manufacturer.

May 2015